



MIDDLE PCB
4999157004




TOP PCB

4999157001




LONG SIDE PCB
(long side to long side)
to use when no top print

4999157002



SHORT SIDE PCB
(long side to long side)
to use with top print

4999157003



BASE PCB (TYPE 157)

